


2-Way Rack Assembly Instructions

Chrome #28201, 28202, 28203, 28528, 28213, 28214, 28215
Black #28210, 28211, 28212



PARTS LIST

Upright/Base Assembly

- A. 1 - Upright
 - B. 1 - Base cover plate
 - C. 1 - Base weight
 - D. 2 - Bolts
 - E. 1 - Allen wrench
 - F. 4 - Adjustable levelers
- 2 - Adjustable rack arms (not shown)

INSTRUCTIONS

1. Remove the 2 bolts (part D) from upright (part A).
2. Insert base weight (part C) into base cover plate (part B).
3. Position the upright (part A) over holes in base.
4. Attach upright through base cover plate part B) and weight (part C) with the two bolts (part D).
5. Tighten bolts securely with wrench (part E).
6. Screw in levelers (part F)

Finally, Slide in arms (pushing buttons) to desired height. Adjust leveler glides as necessary.

